

# HAND WASHING STATION

Item # 3104

845.226.2447

## Instructions:

1. Place unit on a flat level surface. 2. Fill water tank by unhooking the hook located in the upper right hand corner of the unit. Once unhooked, you will be able to see the tank. 3. Open the lid of the water tank and fill with water. Replace the lid and replace the lid in the original position. 4. To activate the water flow simply depress the foot pump. (This will create a steady stream of water to wash your hands with). 5. To place soap in container, locate the button found behind the dispenser. Simply press the button and the lid will detach itself allowing you to place the soap inside. Once filled reattach lid and soap will dispense as needed. 6. To put in paper towels: Insert key into the small white lock on the top of the towel compartment. This will give you access to the towel compartment.



### POWER REQUIREMENTS:



### SPACE REQUIREMENTS:

62"H x 18"W x 22"D



### OPTIONAL EQUIPMENT:



### OTHER REQUIREMENTS:

Water source, soap, paper towels

### Cleaning:

Disposing of gray water: 1. Using a pair of gloves, locate the drain plug found on the bottom left corner of the unit. 2. To dispose of the gray water, simply remove the plug and allow the water to flow out. Once the water container is empty, replace the plug.