

TENT CANOPY

Item # 3470

845.226.2447

INSTRUCTIONS:

Lay the top of the tent out on the grass in a level spot where you would like to have it set up (be sure there are no sharp objects that will rip the tent). Put side poles together and



lay them straight out from all pole holes on the perimeter of the tent. Stake all ropes that reach the end of the poles laying next to the tent. Side poles will be (2) pieces that slide into each other, while the center pole is (4) pieces. Start at opposite corners and slide side poles into pole pockets and raise the tent, while keeping the poles slightly inverted towards the center of the tent. Repeat for other 2 corners and finally side poles. Adjust pole height as necessary. Lastly, construct the center pole and raise the center of the tent.

POWER REQUIREMENTS:



SPACE REQUIREMENTS:

30' x 30'




OPTIONAL EQUIPMENT:

Tables/Chairs




OTHER REQUIREMENTS:

Stakes, hammer, helping hands



Adjust all guy ropes to increase the tension of the tent.



Visti our website or click below for our full step-by-step instructions [Installation Instructions](#)